

Virtual Golf at Hidden Trails Country Club

Virtual Golf is intended for use by **Golf Members only**, or those approved by the Director of Golf, during the cold or rainy season. Use of the Foresight may not be available when weather permits outside play.

How to Use:

3 Main Instructions:

1. **Turn On Projector (Use the remote and point at the projector, press power twice)**
2. **Turn on Foresight Unit on the floor (Press Power once for 1-3 seconds)**
3. **Computer should stay on at all times.**

Once main screen is shown, click Foresight Icon to go to Main Menu of play mode.




Options:

1. **Play:** 10 courses to play, we recommend you set details to 1000 feet above sea level, and Auto 1 Putt each Green. Putting is a nightmare on this thing.
2. **Compete:** Skills Challenge. Lame. Don't do it. It is more frustrating than fun.
3. **Improve:** The Range. This is 80% of all use. Great

tool. Set to 1000 feet about sea level. You can change the green distance at the top left once you get to the range.

Trouble Shoot: Ball does not pick up. Top Right corner button, pull up and find the **Devices** section, make sure it says **Connected**. May Hit the Refresh Icon to populate the **Wired Connection**. If still does not work, press **disconnect** and hit **Connect** again. It should do a 5 second countdown on the screen when the computer acknowledges it. If it still doesn't work, disconnect the Device on the Floor, then reconnect. Wait 30 seconds and see if it populates on the Device Screen. Connect.



When Done:

4 Main Instructions:

1. **Turn Off Projector (Use the remote and point at the projector, press power twice)**
2. **Turn Off Foresight Unit on the floor (Press Power once for 3 seconds)**
3. **Computer should always stay on!!!**
4. **Clean Up**